Support Bulletin

Trimble Penmap Product Family - DWG/DXF file export

GEOSPATIAL

June 2020

The following support bulletin explains what kind of DWG/DXF file exports could be performed with the Penmap Product Family.

Definitions	3
Penmap Product Family	3
Penmap Template	3
Pointstyles and Symbols	3
Point	3
Symbol 1pt	3
Symbol 2pt	3
Export capabilities	3
Penmap for Windows version 10.x and higher	3
Symbol definition	4
Important	5
Penmap Project Manager	5
Important	5
Creating a Penmap Template for DWG/DXF use	6
Contact	6

https://geospatial.trimble.com

www.trimble.com

© 2017, Trimble Inc. All rights reserved. Trimble, the Globe & Triangle logo, are trademarks of Trimble Inc., registered in the United States and in other countries. TMX-2050 is a trademark of Trimble Inc. All other trademarks are the property of their respective owners.



Definitions

Penmap Product Family

The Penmap Product Family contains the following software packages:

- Penmap for Android
- Penmap for Windows
- Penmap Project Manager (including Penmap Cloud Converters)

Penmap Template


The Penmap Template defines layers, styles, symbols and GIS schema which should be used in a Penmap project.


The template definition is a key element for the DWG/DXF export. A Penmap template could be created with Penmap for Windows or with the Penmap Project Manager.

Important: The Penmap Project Manager can not create Penmap templates with symbol support. If symbols are needed, use Penmap for Windows version 10 for the template creation.

Point Styles and Symbols

The Featuretype Point may have different types of graphic elements in Penmap for Windows






Point and Point Styles


The graphic element Point uses the defined Point Style e.g. Cross. The Point Style name is shown below the Style. Point styles are not exportable to AutoCAD.

https://geospatial.trimble.com www.trimble.com



2





Symbol 1pt

The graphic element Symbol uses the defined Symbols.

Symbol 1pt is a symbol with 1 anchor node, which only needs one measurement to define the position. Symbols are exported to AutoCAD as a BLOCK with the Symbol name.

Symbol 2pt

The graphic element Symbol uses the defined Symbols. Symbol 2 pt is a symbol with 2 anchors. First measurement defines the position and a second one the scaling. Symbols are exported to AutoCAD as a BLOCK with the Symbol name



3

Export capabilities


Penmap for Windows version 10.x and higher

Penmap for Windows can export the following things:

- Points (Nodes)
- Lines
- Polylines
- Symbols
- Point Numbers
- Point Codes

Symbol definition

A Symbol needs to be defined in in the *.sdn file of the template. In the iFeature definition the Graphic element Symbol 1pt. or Symbol 2pt. must be selected and a Style (Version 11) /Symbol name (Version 10) needs to be selected.



Version 11 Version 10

Find more information about iFeature handling of Penmap for Windows version 11 in the <u>Trimble Penmap</u> community.


Important

It is **not** possible to export:

- Labels, labels are temporarily labels in Penmap
- GIS data, cause DXF/DWG is an graphic export. Check Shape export or CSV export.



• Point styles in conjunction with the <u>graphic element "Point"</u>, <u>point styles</u> are Penmap only usable point symbols



Penmap Project Manager

Penmap Project Manager can export the following things:

- Points (Nodes)
- Lines
- Polylines
- Symbols

Important

- The DWG/DXF export of the Penmap Project Manager is currently in a beta phase.
- Penmap for Android users can also use Penmap for Windows if more DWG/DXF export capabilities are needed.



Creating a Penmap Template for DWG/DXF use

We recommend using Penmap for Windows to create a compatible DWG/DXF template. There are some differences between version 10.x and the latest version 11.x but the general workflow is the same.

Start Penmap for Windows

- Create a project with the template "empty" or "Blank Template"
- Import a reference DWG / DXF which contains our layers and symbols
- Configure the iFeature system
- Save the template

Find more information about iFeature handling of Penmap for Windows version 11 in the <u>Trimble Penmap</u> community.

Requirements for using DXF/DWG blocks as Penmap symbols:

- Reference points from blocks needs to be inside the block
- Penmap is not able to work with hatches, make sure that block don't contain hatches
- Blocks needs to be lines only

Contact

For more information or questions contact the Trimble Penmap community.

https://community.trimble.com/groups/penmap-for-andriod



https://geospatial.trimble.com

www.trimble.com



7